


J E Sheeran Amusement Arcades Limited

JETSORT 3000 – 6000 SERIES

Head Install Instructions

Unbox the head




Refit the sensors and locating bracket




Refit head to spring loaded hinges


The best way to do this is to hold the head as shown in picture and insert the 4 Allen keys in to the head and finger tightened the bolts.




Once you have got the head secured and lying flat, remove plastic cone from center of the rubber mat with an Allen key




Place wooden template sent back with head into center of turntable while it is locked down and insert Allen key bolt into center and tighten. This will center the head




Now you can tighten the 4 Allen bolts on the spring-loaded hinge. The 2 bolts at the rear should be finger tight and then a quarter turn with the Allen key the two bolts at the front should be tightened with the Allen key



Remove the wooden template and replace the plastic cone in the center of the turntable.



replace the grey plastic cowling and fit 4 screws



your Jetsort is ready to go
J E Sheeran Amusement Arcades Limited
18 Argyle Street, Stonehouse, Lanarkshire, ML9 3LL
tel 01698 792711
Edward@sheeran.co.uk

